



Recoil starter assy.

B&S

Part Number	OEM Number	Description	Product Photo
60-1002	497598 493295	Fits for: B&S Recoil starter assy	
60-1003	497680	Fits for: B&S 12CID Recoil starter assy	
60-1004	633900	Fits for: B&S Recoil starter assy	Photo Not Available 
60-1005	497830 496650 495766 494846 494782	Fits for: B&S 5HP Recoil starter assy	
60-1006	693900	Fits for: B&S Recoil starter assy	
60-1001	499706/690101	Fits for: B&S Recoil starter assy	

Echo

Part Number	OEM Number	Description	Product Photo
60-1501		Fits for: Echo DM621 Recoil starter assy	





Honda

Part Number	OEM Number	Description	Product Photo
60-2001	28400-883-040ZB 28400-ZE1-003ZA 28400-YA0-791	Fits for: Honda G150/200 Recoil starter assy	
60-2002	28400-889-952ZA	Fits for: Honda G300 Recoil starter assy	
60-2003	28400-ZM3-003	Fits for: Honda GX22/31/UT31 Recoil starter assy	
60-2012	28400-ZOH-003	Fits for: Honda GX25 Recoil starter assy	
60-2013	28400-ZOZ-003	Fits for: Honda GX35 Recoil starter assy	
60-2014	28400-Z0D-003ZA	Fits for: Honda GX100 Recoil starter assy	
60-2004	28400-ZH8-013ZA	Fits for: Honda GX110/120/140/160 Recoil starter assy	
60-2005	28410-ZH8-023ZG 28400-ZH8-023YA	Fits for: Honda GX110/120/140/160/GX200 (160KI) Recoil starter assy	



Honda

Part Number	OEM Number	Description	Product Photo
60-2005-1	28410-ZH8-023ZG 28400-ZH8-023YA	Fits for: Honda GX110/120/140/160/GX200 (160K1) Recoil starter assy w/Pulley	
60-2006	28400-ZE2-W01ZA	Fits for: Honda GX240/270 Recoil starter assy	
60-2007	28400-ZE8-8113A 28400-ZE8-811ZA	Fits for: Honda GX340/390 (O) Recoil starter assy	
60-2008	28400-ZE3-W01ZA	Fits for: Honda GX340/390 (N) Recoil starter assy	
60-2009	28400-ZL8-023ZA 28400-ZM0-023ZA	Fits for: Honda GCV135/160/GCV190A Recoil starter assy	
60-2009R	28400-ZL8-013ZB 28400-ZM0-023ZC	Fits for: Honda GCV135/160 Recoil starter assy	
60-2011	28400-ZG9-803 28400-ZG9-802 28400-769-802	Fits for: Honda GXV120/140/160 Recoil starter assy	
60-2010	28400-ZE3-W01ZA 28400-ZE8-811ZA	Fits for: Honda GX340/GX390 (N) Recoil starter assy w/Pulley	
60-2015	28400-ZM7-003	Fits for: Honda GXV50/GXH50 Recoil starter assy	



Kadoris International Corp.

Recoil starter assy.



Honda

Part Number	OEM Number	Description	Product Photo
60-2016	28400-Z1V-003ZB	Fits for: Honda GXV160 (N)/GXV160H2/HR216/HRA216/ HRC216 Recoil starter assy	
	28400-ZE7-003ZA		
	28400-ZE7-003ZB		
	28400-ZE7-003ZC		
60-2018	28400-ZE2-W01ZA	Fits for: Honda GX240/GX270 (N) Recoil starter assy w/Pulley	




Husqvarna

Part Number	OEM Number	Description	Product Photo
60-3010	530 07 19-66	Fits for: Husqvarna 137/142 Recoil starter assy	
60-3001	503 61 55-71	Fits for: Husqvarna 61/266/268 Recoil starter assy	
60-3002	501 81 00-06	Fits for: Husqvarna 281/288 Recoil starter assy	
60-3005	537 42 29-01	Fits for: Husqvarna 340/345/350 Recoil starter assy	
60-3003	503 62 81-71	Fits for: Husqvarna 362/365/371/372 Recoil starter assy	
60-3004	503 60 88-03	Fits for: Husqvarna 51/55 Recoil starter assy	
60-3006	503 46 24-02	Fits for: Husqvarna 395 Recoil starter assy	



Husqvarna

Part Number	OEM Number	Description	Product Photo
60-3007	506 38 56-12	Fits for: Husqvarna K750 Recoil starter assy	
60-3008	506 27 55-01	Fits for: Husqvarna K1250 Recoil starter assy	
60-3009	506 25 95-03	Fits for: Husqvarna K650 Recoil starter assy	

Kawasaki

Part Number	OEM Number	Description	Product Photo
60-4001	49088-2442	Fits for: Kawasaki TH43/48 Recoil starter assy	
60-4003	49088-2166 KS20057BA	Fits for: Kawasaki TD40/48 Recoil starter assy	
60-4004		Fits for: Kawasaki TE59 Recoil starter assy	
60-4002		Fits for: Kawasaki FJ180 Recoil starter assy	



Komatsu

Part Number	OEM Number	Description	Product Photo
60-5201		Fits for: Komatsu G35L/G43L/G45L Recoil starter assy	
60-5202		Fits for: Komatsu Zenoah G2K (O)/G23L/HT2300 Recoil starter assy	
60-5205		Fits for: Komatsu Zenoah G2K (N) Recoil starter assy	
60-5203		Fits for: Komatsu Zenoah G4K/BC4130 Recoil starter assy	
60-5204		Fits for: Komatsu G26/G26L Recoil starter assy	
60-5206		Fits for: Komatsu G3800 Recoil starter assy	
60-5207		Fits for: Komatsu Zenoah G3K Recoil starter assy	



Maruyama

Part Number	OEM Number	Description	Product Photo
60-6201		Fits for: Maruyama 420 Recoil starter assy	
60-6260	263527	Fits for: Maruyama 420 Starter cover only	

Mitsubishi

Part Number	OEM Number	Description	Product Photo
60-6001	KS02037AA	Fits for: Mitsubishi TL33/43/52(Old) Recoil starter assy	
60-6007	KS02060AD	Fits for: Mitsubishi GM82 Recoil starter assy	
60-6002	KS02079AA	Fits for: Mitsubishi TL33/43/52 (New) Recoil starter assy	
60-6002-1	KS02079AA	Fits for: Mitsubishi TL33/43/52 (New) Recoil starter assy w/Pulley	
60-6003	KS20054AA	Fits for: Mitsubishi TU26/TL26//Kaaz Recoil starter assy Triangle	



Mitsubishi

Part Number	OEM Number	Description	Product Photo
60-6003-1		Fits for: Mitsubishi TU26 Square Type	
60-6004	KS20057BA	Fits for: Mitsubishi T200 Recoil starter assy	
60-6006		Fits for: Mitsubishi TB26 (=TL26N) Recoil starter assy	
60-6006-1		Fits for: Mitsubishi TB26 (=TL26N) Recoil starter assy w/Pulley	Photo Not Available 
60-6005		Fits for: Mitsubishi TB33/43/52 Recoil starter assy	
60-6005-1		Fits for: Mitsubishi TB33/43/52 Recoil starter assy w/Pulley	
60-6003-2		Fits for: Mit.TU26/TL26//Kaaz (Easy starter) Recoil starter assy (for Brushcutter)	
60-6008		Fits for: Mitsubishi GM182/GT600 (6HP) Recoil starter assy	



Robin

Part Number	OEM Number	Description	Product Photo
60-7007		Fits for: Robin EC04/NB411	
60-7011	268-50201-00	Fits for: Robin EH12	
60-7002		Fits for: Robin EY15 (N)	
60-7003	226-50811-00	Fits for: Robin EY15 (O)	
60-7004	227-50811-10 227-50211-00 227-50211-01 227-50405-00 282-50211-00	Fits for: Robin EY20(N)	
60-7005		Fits for: Robin EY20(O)	
60-7005-1		Fits for: Robin EY20(O) Recoil starter assy w/pulley (cup)	Photo Not Available 



Robin

Part Number	OEM Number	Description	Product Photo
60-7006	269-50201-30	Fits for: Robin EX17/EH17/EY17	
60-7009		Fits for: Robin EY28 (Speed) Standard: Right Recoil starter assy w/pulley (cup)	
60-7010		Fits for: Robin EY28 (Slow) Standard: Left Recoil starter assy w/pulley (cup)	Photo Not Available

Oleomac

Part Number	OEM Number	Description	Product Photo
60-7201	50012069BR	Fits for: Oleomac 956/962	



Shindaiwa

Part Number	OEM Number	Description	Product Photo
60-8001	70012-75100	Fits for: Shin.C35/C350/BP40L	
60-8002	70020-75100	Fits for: Shin.B45/B450/BP45L	

Stihl

Part Number	OEM Number	Description	Product Photo
60-3512	1130-080-2100	Fits for: Stihl 017/018/MS170/MS180	
60-3509	1123-080-2104	Fits for: Stihl 021/023/025/MS210/MS230/MS250	
60-3502	1121-080-2101 1121-080-1812	Fits for: Stihl 024/026/MS240/MS260	
60-3513	1127-080-2103	Fits for: Stihl 029/MS290/MS310/MS390	
60-3503	1125-080-2105	Fits for: Stihl 034/036/MS340/MS360	



Stihl

Part Number	OEM Number	Description	Product Photo
60-3501	1119-080-1800	Fits for: Stihl 038	
60-3504	1128-080-2104	Fits for: Stihl 044/046/MS440/MS460	
60-3507	1122-080-2101 1122-080-2110	Fits for: Stihl 064/066/MS640/MS660	
60-3505	4203-190-0405	Fits for: Stihl BR320/BR340/BR380/BR400/BR420/ SR320/SR340/SR400/SR420	
60-3506	1108-080-2101	Fits for: Stihl TS350/TS360	
60-3508	4223-190-0401	Fits for: Stihl TS400	
60-3511	1135-080-2102	Fits for: Stihl MS341/MS361	
60-3510	4119-190-0401	Fits for: Stihl FS160/FS220/FS280	



Stihl

Part Number	OEM Number	Description	Product Photo
60-3514	4238-190-0302 4238-190-0300	Fits for: Stihl TS410/TS420	
60-3515	4224-190-0306	Fits for: Stihl TS700	

Tanaka

Part Number	OEM Number	Description	Product Photo
60-8601		Fits for: Tanaka 328	
60-8602		Fits for: Tanaka 340/410	

Tecumseh


Part Number	OEM Number	Description	Product Photo
60-7501	590420A 590706 14210090	Fits for: Tecumseh H22/40	
60-7502	590737 590686 590621 590086 14210056 14210076	Fits for: Tecumseh H30-70/HS40-50(N)	



Wacker

Part Number	OEM Number	Description	Product Photo
60-9501	46098	Fits for: Wacker WM80/BH22/BH23/BH24/BS30/BS500/BS50-2/BS52Y/BS60-2/BS600/BS650/BS65Y/BS70-2/BS700	

Yamaha

Part Number	OEM Number	Description	Product Photo
60-9601		Fits for: Yamaha MZ175	
60-9602		Fits for: Yamaha ET950	
60-9603		Fits for: Yamaha MZ360/EF6600	

Yanmar

Part Number	OEM Number	Description	Product Photo
60-9701	714250 76810	Fits for: Yanmar L40	
60-9702		Fits for: Yanmar L-60/L-70	



Recoil starter kits

B&S

Part Number	OEM Number	Description	Product Photo
60-1051	399676	Fits for: B&S Flywheel Ring gear	
60-1052	495877	Fits for: B&S Gear assy.	
60-1053	495878	Fits for: B&S Gear assy.	
60-1054	497606	Fits for: B&S Gear assy.	
60-1055	497606	Fits for: B&S Gear Retain	
60-1056	280104//M83184	Fits for: B&S//John deere Gear	

Honda

Part Number	OEM Number	Description	Product Photo
60-2060	90008-ZE2-003	Fits for: Honda GX120/GX160/GX200/XG240/GX270/ GX340/GX390/GX610/GX620/GXV610/GXV6200 Bolt , Flange Standard :6x10	



Stihl

Part Number	OEM Number	Description	Product Photo
60-3562	4119-190-0401	Fits for: Stihl FS160/FS180/FS220/FS280/FS290 Recoil case only	

Mitsubishi

Part Number	OEM Number	Description	Product Photo
60-6060	KS02037AA001	Fits for: Mitsubishi TL33/43/52 Recoil case only	Photo Not Available 

Shindaiwa

Part Number	OEM Number	Description	Product Photo
60-8061	11002-40122	Fits for: Shin. C35 Recoil case only	Photo Not Available 

60-8062	11002-10123	Fits for: Shin. B45 Recoil case only	Photo Not Available 
----------------	-------------	---	--

Husqvarna

Part Number	OEM Number	Description	Product Photo
60-3068	503 60 86-01	Fits for: Husqvarna 51/55 Starter cover only	Photo Not Available 

Webb

Part Number	OEM Number	Description	Product Photo
60-9551	LM656/W29676	Fits for: Webb (Fits 24"Webb) Drive gear	



Husqvarna

Part Number	OEM Number	Description	Product Photo
60-3063	503 61 56-01	Fits for: Husqvarna 61(New) Starter/side cover	
60-3063-S	503 61 56-01	Fits for: Husqvarna 61(New) Starter/side cover w/screws	
60-3060	503 61 56-01	Fits for: Husqvarna 266(O) Starter/side cover	
60-3061	501 81 01-05	Fits for: Husqvarna 288 Fan cover	
60-3069	503 62 82-02	Fits for: Husqvarna 362/365/371/372 Starter cover only	
60-3064	501 68 60-01 501 68 60-04	Fits for: Husqvarna 61(O)/266 Top cover	
60-3065	503 61 00-03 503 61 00-04	Fits for: Husqvarna 61(N)/266 Top cover	
60-3066	503 20 34-16	Fits for: Husqvarna 61/261/266/272 Standard: 19.3x9.6mm Screw for stop/top cover	



Husqvarna

Part Number	OEM Number	Description	Product Photo
60-3067	503 20 32-28(29)	Fits for: Husqvarna 61/266/268 Standard: L :30x W :8mm Screw for stop/top cover	
60-3062	537 42 34-01	Fits for: Husqvarna 340/345/350 (N) Reel spring	
60-3071	501 51 54-01	Fits for: Husqvarna 61/268/272/281/288 Plug for Top cover	
60-3070	503 74 01-02/01	Fits for: Husqvarna 365 Clip	

Stihl

Part Number	OEM Number	Description	Product Photo
60-3561	1119-080-1680	Fits for: Stihl 038 Handle shroud	Photo Not Available 
60-3563	1113-140-9200	Fits for: Stihl 038/G30/G32 Twist look	Photo Not Available 



Cover

Oleomac

Part Number	OEM Number	Description	Product Photo
60-7260	50022055	Fits for: Oleomac 956/962 Cover	

Stihl

Part Number	OEM Number	Description	Product Photo
60-3560	4238-080-3100	Fits for: Stihl TS410/TS420 Fan cover	



Kadoris International Corp.

Starter handle





Kadoris International Corp.

Starter handle



Starter handle

B&S

Part Number	OEM Number	Description	Product Photo
61-1001	280036 491288	Fits for: B&S Standard: Black	
61-1002	393152	Fits for: B&S	
61-1004	490652	Fits for: B&S	
61-1005	609477	Fits for: B&S Standard: White	
61-1006	281434S	Fits for: B&S	

Echo

Part Number	OEM Number	Description	Product Photo
61-1501	177228-06530	Fits for: Echo PB-210/PB-260/CS-330EVL/DH212/ES-2100/ES-2400	



Honda

Part Number	OEM Number	Description	Product Photo
61-2001	28461-ZG0-004 28461-ZE8-811	Fits for: Honda fit all small model	
61-2002	28461-ZE1-003 28461-ZE1-013	Fits for: Honda fit all small model	
61-2003		Fits for: Honda GX390	
61-2004	28461-ZL8-003	Fits for: Honda GCV135/160	
61-2005	28461-ZH8-003	Fits for: Honda GXV160/GX110-390/GX100	
61-2007	28461-ZM3-003	Fits for: Honda GX22/31/25/35	

Husqvarna

Part Number	OEM Number	Description	Product Photo
61-3001	501 52 79-62 501 55 14-01 503 54 39-01	Fits for: Husqvarna Universal	



Lawn-Boy

Part Number	OEM Number	Description	Product Photo
61-5401	609477 606863	Fits for: Lawn-Boy	

Mitsubishi

Part Number	OEM Number	Description	Product Photo
61-6001		Fits for: Mitsubishi TL43 (New) Universal	

MTD

Part Number	OEM Number	Description	Product Photo
61-6501	720-04049A	Fits for: MTD Standard: 3/8" Yard Machines Handle grip,	
61-6502	720-0311	Fits for: MTD Standard: 1/2" Grip handle	

Stihl

Part Number	OEM Number	Description	Product Photo
61-3501	1121-195-3400 1107-195-8200 1110-195-3400	Fits for: Stihl 09/011/017/018/024/026/051/070/076/08/090/TS400/TS410	
61-3502		Fits for: Stihl Chain Saw Universal Standard: 4.0mmx110cm Starter handle w/rope	



Kadoris International Corp.

Starter handle



Stihl

Part Number	OEM Number	Description	Product Photo
61-3503	1122-190-3400	Fits for: Stihl Chain Saw Universal Standard: 4.5mmx110cm Starter handle w/rope	
61-3504	0000-190-3400	Fits for: Stihl FS350/400/450 Standard: 3.0mmx100 cm Starter handle w/rope	
61-3505	0000-190-3400	Fits for: Stihl FS350/400/450 Standard: 3.5mmx110 cm Starter handle w/rope	
61-3506	1128-190-3400	Fits for: Stihl Chain Saw Universal Standard: 3.5mmx110cm Starter handle w/rope	

Partner

Part Number	OEM Number	Description	Product Photo
61-7301	503 12 79-01 503 12 79-02	Fits for: Husqvarna K650/K750/K760/K950/K960/K970/ K1250/K1260	

Suffolk

Part Number	OEM Number	Description	Product Photo
61-8401	L11932	Fits for: Suffolk SP33	



Tanaka

Part Number	OEM Number	Description	Product Photo
61-8601	785-10207-201 46075-2014	Fits for: Tanaka 318/328//Kawasaki TD40(Old)	

Tecumseh

Part Number	OEM Number	Description	Product Photo
61-7501	590387	Fits for: Tecumseh	
61-7502	590574 315542 PT10615	Fits for: Tecumseh//Murry//NOMA//TORO//ARIEN// Johndeer	

Weedeater

Part Number	OEM Number	Description	Product Photo
61-9301	530-024451	Fits for: Weedeater Standard: 4.0mmx80cm Starter handle w/rope	

Others

Part Number	OEM Number	Description	Product Photo
61-9501	13833	Fits for: Door handle	